

THE SPEED INSTALL

By **SYLVANIA** & **PRO-WIRE**

Try this system on your next install. It will greatly reduce termination time, drive sales of Jack Plates and leave a legacy behind you of the cleanest install in the business with INDUSTRY STANDARD banana plugs.

Step 1 Bring speaker wires into back of J-box or mud ring.

Step 2 Use crimp-on banana plugs to QUICKLY terminate wires to back side of back-to-back 5-Way binding posts.

Step 3 Use one of the *NEW* Sylvania speaker switchers with the revolutionary MB-4 wiring harness connection system.

Simply plug the pre-terminated and pre-labeled high grade banana plugs into the front side of the IWM 5-Way binding posts.

Step 4 Plug the 16 conductor nylon plug(s) on the MB-4 into the back of the Sylvania switcher. Each 16 conductor harness provides connections for 4 pairs of speakers.

